



**SENSOR-
ACCELERATOR
PEDAL POSITION**

SENSOR-ACCELERATOR PEDAL POSITION - BLACK 6 WAY

CAV	CIRCUIT	FUNCTION
1	F856 20YL/PK (DIESEL)	ACCELERATOR PEDAL POSITION SENSOR NO. 2 5 VOLT SUPPLY
1	F856 20YL/PK (GAS)	5 VOLT SUPPLY
2	K29 20WT/BR (DIESEL)	ACCELERATOR PEDAL POSITION SENSOR NO. 2 SIGNAL
2	K29 20WT/BR (GAS)	APPS NO. 2 SIGNAL
3	K400 20BR/VT (DIESEL)	ACCELERATOR PEDAL POSITION SENSOR NO. 2 GROUND
3	K400 20BR/VT (GAS)	APPS NO. 2 RETURN
4	K167 20BR/YL (DIESEL)	ACCELERATOR PEDAL POSITION SENSOR NO. 1 GROUND
4	K167 20BR/YL (GAS)	APPS NO. 1 RETURN
5	K23 20BR/WT (DIESEL)	ACCELERATOR PEDAL POSITION SENSOR NO. 1 SIGNAL
5	K23 20BR/WT (GAS)	APPS NO. 1 SIGNAL
6	F855 20PK/YL (DIESEL)	ACCELERATOR PEDAL POSITION SENSOR NO. 1 5 VOLT SUPPLY
6	F855 20PK/YL (GAS)	5 VOLT SUPPLY